2015 RAM 2500/3500 SNOWPLOW INSTALLATION GENERAL GUIDELINES

INTRODUCTION

The factory-installed Snowplow Preparation Groups or their equivalent components) are recommended and listed for each vehicle. The normal warranty applies to Ram trucks that have after market snowplows installed in accordance with these guidelines.

Maximum Vehicle Loading Requirements:

Installation of snowplows and their mounting hardware may result in a vehicle weight distribution or a front axle loading which is detrimental to brake performance or which exceeds the front GAWR. The following load requirements are applicable:

- The loaded vehicle, including all after market accessories, the snowplow system, passengers, and cargo, must not exceed the gross vehicle weight (GVW), front or rear gross axle weight (GAW) ratings specified on the Safety Compliance Certification label located in the driver's side door opening.
- 2. The empty truck with all permanently attached accessories and snowplow components must not exceed 62 percent of its total weight on the front axle to comply with FMVSS/CMVSR 105 Brake Certification. Permanently attached snowplow parts are those parts not easily removed when the blade is removed. The permanently attached parts are: subframe, hydraulic pump, hydraulic lift cylinder, lamps, wiring, snowplow controls, etc.

If the front axle loading exceeds either 62 percent of the empty truck total weight, or the front GAWR, ballast-compensating weight must be securely attached at the rear of the truck to bring front axle weight within weight specifications as defined above.

Notes for Heavy Duty Snowplows:

- At any time, the maximum number of occupants in the truck must not exceed two
- Under Any Circumstances, vehicles should NOT exceed GVWR (Gross Vehicle Weight Rating), Front or Rear GAWRs (Gross Axle Weight Ratings)
- Cargo capacity will be reduced by the addition of options.
- Ballast should be securely attached inside the box at 9 inches from the rear tailgate for pickups.
- The total weight of permanently attached hardware should not exceed 125 lbs.
- Max snowplow weight should not exceed values for models shown in this section.

The snowplow weights shown in the charts on the next page are the manufacturer recommendations based on maximum vehicle option content. Other plow weight values may be possible, based on the specific capability of the vehicle being modified (actual weight, GVWR, front and rear GAWR). The maximum allowable plow weight can be determined by the dealer /supplier / manufacturer. In all cases, the loaded vehicle weight, including the snowplow system, all aftermarket accessories, driver, passengers, options, and cargo, must not exceed either the Gross Vehicle Weight (GVWR) or Gross Axle Weight (GAWR) ratings. The GVWR and GAWR weights are specified on the Safety Compliance Certification Label on the driver's side door opening.



Safety Compliance Certification Label